

LIFS

MORN

Sky Tang

+86-189 0541 5749(Whatsapp/Viber/Wechat)

JINAN MORN TECHNOLOGY (MORN GROUP LIMITED) CO., LTD

Specifications of Wheelchair lift		
Model	WL0.3-2.5	
Lift capacity	300kg	
Travel Height	2500mm	
Platform size	1430*1000mm	
In and out	Customized	
Power Input	Customized according to your local voltage.	
Speed	0.1m/s	

Convenient And Safety Design

1.Drive System : Hydraulic

2.Control Mode : Inching Switch on platform and column

3. Control ways : Control panel on platform and vertical control column on ground and second floor.

4. Double tempered glass full cover

5.Automatic door: Acrylic

5. Working Condition : Indoor or outdoor

6.Installation : Non-pit installation, directly fixed to concrete floor (the concrete

floor below the platform shall not be lower than the ground)

Safely Device:Reliable

1. Bottom Safety Sensor : The lift will be stopped immediately if the safety edge meets obstacles when going down.

- 2. Emergency Stop : The lift can be stopped immediately in case of any emergency.
- 3. Manual decline: The lift can manually decline when the electricity failure.

Price And Warranty		
Payment terms	100% TT before production	
Delivery time	30 Working days from payment	
Price Validity	15 days	
Warranty	12 months, apart from man-made fault	







Safety specs

Material

 The lifts use T6063 aluminum alloy, which has good mechanical intensity and corrosion resistance and weather resistance. Ensure the lift 15 years structural warranty.
Hardness > 2h, it is not easy to be scratched

3. We make it white powder coating, it looks

more beautiful, it can match with all kinds of buildings;

Double layered tempered glass:

Strong glass which is not easy to be broken and efficiently secure your safety.

Bottom safety sensor:

There are safety sensors on the four corners and middle of the platform bottom. The lift will be stopped immediately if the bottom meets obstacles when lifting down.

Manual decline valve:

The platform can be lowered down by manual down button in case of the electricity is suddenly Interrupt.













control plate

control panel

0

Remote control (optional)

8888



Lift system



Acrylic door

Motor



